

**CAMPING VARIO BASIC
CAMPING CHEF VARIO
CAMPING VARIO DELUXE**




CAMPING VARIO BASIC



CAMPING CHEF VARIO



CAMPING VARIO DELUXE



| REF . | POINTS | GB DESIGNATIONS | DESIGNATIONS F | VARIO BASIC | CHEF VARIO | VARIO DELUXE |
|------------|--------|--------------------------|--------------------------|-------------|------------|--------------|
| 5010001101 | 50 | BURNER | BRULEUR | X | X | X |
| 5010001102 | 40 | KNOB (x3) | VOLANT (x3) | X | X | X |
| 5010001103 | 30 | PAN SUPPORT | SUPPORT DE CASSEROLE | X | X | X |
| 5010001104 | 70 | TOASTER | TOASTER | | X | X |
| 5010001105 | 60 | LEFT + RIGHT WINDSHIELDS | PAREVENTS DROIT + GAUCHE | | X | X |
| 5010001204 | 50 | PIEZO | PIEZO | X | X | X |
| 5010001106 | 50 | PACKAGING | EMBALLAGE | X | | |
| 5010001107 | 50 | PACKAGING | EMBALLAGE | | | X |
| 5010001108 | 50 | PACKAGING | EMBALLAGE | | X | |