

**CAMPING VARIO BASIC  
CAMPING CHEF VARIO  
CAMPING VARIO DELUXE**




**CAMPING VARIO BASIC**



**CAMPING CHEF VARIO**



**CAMPING VARIO DELUXE**



| REF .      | POINTS | GB DESIGNATIONS          | DESIGNATIONS F           | VARIO BASIC | CHEF VARIO | VARIO DELUXE |
|------------|--------|--------------------------|--------------------------|-------------|------------|--------------|
| 5010001101 | 50     | BURNER                   | BRULEUR                  | X           | X          | X            |
| 5010001102 | 40     | KNOB (x3)                | VOLANT (x3)              | X           | X          | X            |
| 5010001103 | 30     | PAN SUPPORT              | SUPPORT DE CASSEROLE     | X           | X          | X            |
| 5010001104 | 70     | TOASTER                  | TOASTER                  |             | X          | X            |
| 5010001105 | 60     | LEFT + RIGHT WINDSHIELDS | PAREVENTS DROIT + GAUCHE |             | X          | X            |
| 5010001204 | 50     | PIEZO                    | PIEZO                    | X           | X          | X            |
| 5010001106 | 50     | PACKAGING                | EMBALLAGE                | X           |            |              |
| 5010001107 | 50     | PACKAGING                | EMBALLAGE                |             |            | X            |
| 5010001108 | 50     | PACKAGING                | EMBALLAGE                |             | X          |              |