

**PARTY GRILL PG 400 / 600  
600 COMPACT**



**PG 400**






**PG 600**









**PG 600  
COMPACT**

# PARTY GRILL PG 400 / 600 600 COMPACT

## PG 400



## PG 600



SPARE PARTS REF.	EN DESCRIPTIONS	FR DESCRIPTIONS	PG 400	PG 600	PG 600 COMPACT
2195234	LID HANDLE	POIGNEE COUVERCLE		X	X
5010002634	THERMOMETER WITH BEZEL	THERMOMETRE AVEC COUPELLE		X	
5010003810	PAN SUPPORT	BRAS SUPPORT	X		
5010003811	KIT 3 LEGS	KIT 3 PIEDS	X		
5010003819	HEAT DISTRIBUTING PLATE	PLATEAU REPARTITEUR DE CHALEUR	X		
5010003824	REVERSIBLE CAST IRON COOKING GRIDDLE	PLAQUE DE CUISSON FONTE REVERSIBLE	X		
5010003825	LID WITH HANDLES, SCREWS AND PLASTIC WASHERS	COUVERCLE AVEC POIGNEES, VIS ET RONDELLES EN PLASTIQUE	X		
5010003836	STEEL COOKING GRID	GRILLE DE CUISSON ACIER	X		
5010003837	KIT PIEZO + ELECTRODE + KNOB	KIT PIEZO + ELECTRODE + VOLANT	X	X	X
5010003838	KIT LEGS	KIT PIEDS		X	X
5010003839	HEAT DISTRIBUTING PLATE	PLATEAU REPARTITEUR DE CHALEUR		X	X
5010003840	PAN SUPPORT	BRAS SUPPORT		X	X
5010003841	REVERSIBLE CAST IRON COOKING GRIDDLE	PLAQUE DE CUISSON FONTE REVERSIBLE		X	X
5010003842	STEEL COOKING GRID	GRILLE DE CUISSON ACIER		X	X
5010003843	LID WITHOUT HANDLE	COUVERCLE SANS POIGNEE		X	
5010003844	LOWER PLASTIC SHELF	ETAGERE PLASTIQUE		X	X
5010005838	PLASTIC CAP	COUVERCLE PLASTIQUE			X
5010005873	BURNER	BRULEUR	X		