

BARBECUES : 2 SERIES CLASSIC

**L - CLASS 2L - LX - LX VARIO - LX VARIO+
 CLASS 2 LX VARIO - LX PLUS - LX PLUS VARIO
 CLASS 2 LX PLUS VARIO - LX PLUS D - LX D PLUS VARIO
 EXS - EXS VARIO - EXS VARIO D - LXS**



**2 SERIES CLASSIC L
 CLASS 2 L**



MOD. 2018



**2 SERIES CLASSIC LX
 2 SERIES CLASSIC LX VARIO
 2 SERIES CLASSIC LX VARIO +
 CLASS 2 LX VARIO**



MOD. 2018



**2 SERIES CLASSIC LX
 PLUS**



**CLASS 2 LX PLUS VARIO
 2 SERIES CLASSIC LX PLUS VARIO**



**2 SERIES CLASSIC
 LX D PLUS VARIO**



**2 SERIES CLASSIC LX
 PLUS D**



**2 SERIES CLASSIC EXS
 2 SERIES CLASSIC EXS VARIO**




2 SERIES CLASSIC EXS VARIO D



2 SERIES CLASSIC LXS

BARBECUES : 2 SERIES CLASSIC

**L - CLASS 2L - LX - LX VARIO - LX VARIO+
CLASS 2 LX VARIO - LX PLUS - LX PLUS VARIO
CLASS 2 LX PLUS VARIO - LX PLUS D - LX D PLUS VARIO
EXS - EXS VARIO - EXS VARIO D - LXS**




BARBECUES : 2 SERIES CLASSIC

**L - CLASS 2L - LX - LX VARIO - LX VARIO+
 CLASS 2 LX VARIO - LX PLUS - LX PLUS VARIO
 CLASS 2 LX PLUS VARIO - LX PLUS D - LX D PLUS VARIO
 EXS - EXS VARIO - EXS VARIO D - LXS**

TROLLEY / CHARIOT


BEFORE / AVANT 2018



5010004946
 Screw bag
 Sacs de vis


FROM / A PARTIR DE 2018

MODEL WITHOUT DOORS / MODELE SANS PORTES



5010004946
 Screw bag
 Sacs de vis

MODEL WITH DOORS / MODELE AVEC PORTES



5010004946
 Screw bag
 Sacs de vis

BARBECUES : 2 SERIES CLASSIC

L - CLASS 2L - LX - LX VARIO - LX VARIO+
 CLASS 2 LX VARIO - LX PLUS - LX PLUS VARIO
 CLASS 2 LX PLUS VARIO - LX PLUS D - LX D PLUS VARIO
 EXS - EXS VARIO - EXS VARIO D - LXS



SPARE PARTS REF.	EN DESCRIPTIONS	FR DESCRIPTIONS	2 CLASSIC L - 2 CLASSIC LX 2 CLASSIC LX VARIO - 2 CLASSIC LX VARIO + CLASS 2L - CLASS 2 LX VARIO	2 CLASSIC LX PLUS - LX PLUS VARIO CLASS 2 LX PLUS VARIO - 2 CLASSIC LX PLUS D 2 CLASSIC LX D PLUS VARIO	2 CLASSIC EXS - 2 CLASSIC EXS VARIO EXS VARIO D	2 CLASSIC LXS
40012ZCL	COMPLETE BURNER FOR SIDE STOVE	BRULEUR POUR RECHAUD LATERAL			X	X
73463	PAN SUPPORT	SUPPORT DE CASSEROLE			X	X
5010001024	HANDLE / USTENSIL HOLDER	POIGNEE / PORTE USTENSILE		X	X	
5010001487	GREASE CAN + WIRE	POT A GRAISSE + FIL	X	X	X	X
5010002176	KIT OF 2 KNOBS FOR SIDE STOVE	KIT DE 2 VOLANTS POUR RECHAUD LATERAL			X	X
5010002214	PIEZO 1 OUTLET	PIEZO SIMPLE	X	X		
5010002298	BURNER (STAINLESS STEEL TOP / STEEL BOTTOM) WITH SUPPORT	BRULEUR (PARTIE SUP. INOX / PARTIE INF. ACIER) AVEC ENTRETOISE	X	X	X	X
5010002299	TOP + BOTTOM FRONT PANEL - LIGHT GREY	PANNEAU AVANT HAUT + BAS - GRIS CLAIR	X			X
5010002300	WARMING RACK	GRILLE DE MIJOTAGE	X	X	X	X
5010002301	RIGHT OR LEFT SIDE SHELF	ETAGERE LATERALE DROITE OU GAUCHE	X	X	X	X
5010002302	ENAMELLED STEEL COOKING GRID - SHINY	GRILLE DE CUISSON ACIER EMAILLE - BRILLANTE	X	X		X
5010002303	HEAT DIFFUSER (x1)	DIFFUSEUR DE CHALEUR (x1)	X	X	X	X
5010002304	CANISTER SUPPORT	SUPPORT DE RESERVOIR	X	X	X	
5010002305	GAS PIPE 28Mb (Export)	TUBULURE 28Mb (Export)	X	X		
5010002306	LID WITHOUT HANDLE - BLACK	COUVERCLE SANS POIGNEE - NOIR	X	X	X	X
5010002308	WHEEL AXLE	AXE DE ROUE	X	X	X	X
5010002309	LEFT SIDE SHELF SUPPORT	SUPPORT GAUCHE ETAGERE	X	X	X	X
5010002310	RIGHT SIDE SHELF SUPPORT	SUPPORT DROITE ETAGERE	X	X	X	X
5010002311	BASE	CUVE	X	X	X	X
5010002312	ELECTRODE + WIRE + SUPPORT	ELECTRODE + FIL + SUPPORT	X	X	X	X
5010002313	KNOB (x2)	VOLANT (x2)	X	X	X	X
5010002315	GAS PIPE 50Mb 1/4" (De)	TUBULURE 50Mb 1/4" (De)	X	X		
5010002316	GAS PIPE 28Mb 1/4" (Ch)	TUBULURE 28Mb 1/4" (Ch)	X	X		
5010002317	KIT HANDLE FOR LID	KIT POIGNEE POUR COUVERCLE	X	X	X	X
5010002318	THERMOMETER	THERMOMETRE	X	X	X	X
5010002319	PLASTIC FOOT (X1)	PIED PLASTIQUE (X1)	X	X	X	X
5010002320	UPPER + LOWER HINGE	CHARNIERE HAUT + BAS	X	X	X	X
5010002321	GAS PIPE 28Mb 1/2" (Fr)	TUBULURE 28Mb 1/2" (Fr)	X	X		
5010002322	STOVE PIPE 28Mb (Export)	TUBULURE RECHAUD 28Mb (Export)			X	X
5010002328	ENAMELLED STEEL COOKING GRIDDLE - SHINY	PLAQUE DE CUISSON ACIER EMAILLE - BRILLANTE	X	X		
5010002329	SIDE SHEET	TOLE LATERALE		X	X	

BARBECUES : 2 SERIES CLASSIC

L - CLASS 2L - LX - LX VARIO - LX VARIO+
 CLASS 2 LX VARIO - LX PLUS - LX PLUS VARIO
 CLASS 2 LX PLUS VARIO - LX PLUS D - LX D PLUS VARIO
 EXS - EXS VARIO - EXS VARIO D - LXS



SPARE PARTS REF.	EN DESCRIPTIONS	FR DESCRIPTIONS	2 CLASSIC L - 2 CLASSIC LX 2 CLASSIC LX VARIO - 2 CLASSIC LX VARIO + CLASS 2L - CLASS 2 LX VARIO	2 CLASSIC LX PLUS - LX PLUS VARIO CLASS 2 LX PLUS VARIO - 2 CLASSIC LX PLUS D 2 CLASSIC LX D PLUS VARIO	2 CLASSIC EXS - 2 CLASSIC EXS VARIO EXS VARIO D	2 CLASSIC LXS
5010002330	RIGHT OR LEFT DOOR WITHOUT HANDLE (LIGHT GREY)	PORTE DROITE OU GAUCHE SANS POIGNEE (GRIS CLAIR)		X	X	
5010002331	DOOR AXLE	AXE DE PORTE		X	X	
5010002332	SIDE STOVE SHELF	ETAGERE RECHAUD LATERAL			X	X
5010002335	SIDE BURNER ELECTRODE	ELECTRODE RECHAUD LATERAL			X	X
5010002336	CAST IRON ENAMELLED COOKING GRID - SHINY	GRILLE DE CUISSON FONTE EMAILLEE - BRILLANTE			X	
5010002337	REVERSIBLE CAST IRON ENAMELLED COOKING GRIDDLE - SHINY	PLAQUE DE CUISSON FONTE EMAILLEE REVERSIBLE - BRILLANTE			X	
5010002350	STEEL BURNER WITH SUPPORT	BRULEUR ACIER AVEC ENTRETOISE	X	X	X	
5010002407	DOOR ACCESSORY BAG	SACHET ASSESSOIRES PORTE		X	X	
5010002423	CONTROL PANEL (2 Classic L)	CONSOLE (2 Classic L)	X	X	X	
5010002424	CONTROL PANEL (Class 2L)	CONSOLE (Class 2L)	X			
5010002516	GAS TUBE HOLDER	SUPPORT TUBULURE	X	X	X	X
5010002517	TUBE JUNCTION FOR 2014 TROLLEY	SUPPORT POUR CHARIOT 2014	X	X	X	
5010003304	ENAMELLED CAST IRON COOKING GRID - MATTE	GRILLE DE CUISSON FONTE EMAILLEE - MATE	X	X	X	
5010003313	CARRIAGE	CHARIOT	X	X	X	
5010004945	CYLINDER SUPPORT + TROLLEY	SUPPORT BOUTEILLE + CHARIOT	X		X	X
5010004946	SCREW BAG	SACHET DE VIS	X	X	X	X
5010005365	PIEZO DOUBLE	PIEZO DOUBLE			X	X
5010005551	WHEEL DIAMETER 160 (X 1) WITH CHROMED CAP	ROUE DIAMETRE 160 (X 1) AVEC ENJOLIVEUR CHROME	X	X	X	X
5010005553	CONTROL PANEL (2 SERIES CLASSIC EXS)	CONSOLE (2 SERIES CLASSIC EXS)			X	X
5010005556	RIGHT OR LEFT DOOR WITHOUT HANDLE (DARK GREY)	PORTE DROITE OU GAUCHE SANS POIGNEE (GRIS FONCE)		X		